

Tractor Installation Overview




Remove wheel & mounting hub



Install oscillation stops on tractor frame

Sketch 4



Reinstall the mounting hub



Install adaptor plate to axle hub



Mount module to adaptor plate